

*User's Guide*

*Service Addendum*

# **Amiga CD<sup>32</sup>**

**July 1993**

**371223-01**

## Chapter 5

# Bill of Materials

---

The following information is taken from the Amiga CD<sup>32</sup> Bill of Materials (BOM).

- Title of the drawing
- Number and revision level of the drawing
- Part number of each part
- Description of each part
- Reference description/notes for each part

The BOM contains additional product configuration data not reproduced in this table. The BOM is updated periodically. For a complete current listing of all the information contained in a BOM (including line item numbers), request the latest revision BOM drawings (by drawing number) from Engineering Documentation in West Chester.

Bracket	Description
[ ]	National Television Standard Committee (NTSC) US television standard
( )	Phase Alternation Line (PAL) European television standard
{ }	Notes

---

### PCB Assembly, CD Game System (365101 Rev D)

---

365101-01	PCB Assembly, CD Game System, NTSC	
365101-02	PCB Assembly, CD Game System, PAL	
365100-01	Schematic, CD Game System	
365103-01	PCB Fab, CD Game System	
365102-01	Functional Spec, CD Game System	
365104-01	Artwork, CD Game System	
	<b>INTEGRATED CIRCUITS</b>	
391506-01	IC, CPU, MC68EC020, 16 mHz, 100-Pin PQFP	U1
391010-01	IC, 8374, ALICE, 84-Pin PLCC	U2
391227-01	IC, 4203, LISA, 84-Pin PLCC	U4
391077-01	IC, 8364R7, PAULA, 52-Pin PLCC	U3
391563-01	IC, GATE ARRAY, Akiko, 160-Pin PQFP	U5
391624-01	IC, 74F00, SM, EIAJ	U25; Substitute for PN 391139-01
391547-01	IC, 74LS166, SM, EIAJ	U34; Substitute for PN 391426-01
391655-01	IC, 74F373, SM, EIAJ	U35; Substitute for PN 391376-01
391548-01	IC, 74F86, SM, EIAJ	U37; Substitute for PN 391325-01
391139-01	IC, 74F00, SM	U25
391426-01	IC, 74LS166, SM	U34
391376-01	IC, 74F373, SM	U35

PCB Assembly, CD Game System (365101 Rev D)		(cont'd)
391325-01	IC, 74F86, SM	U37
391141-01	IC, SM, 74LS74A	U33
391311-01	IC, 74HC4066, SM	U22, U36
391283-02	IC, Voltage Detector, RH5VA43A, SM	U14, U49
391599-02	IC, DRAM, 512Kx8, 80ns, SM	U16-U19
391640-01	IC, ROM, Kickstart, CDGS, 512kx16, 42-Pin DIP	U6
391084-01	IC, Video Encoder, CXA1145M, SM	U12
391422-01	IC, Video DAC, BT101, 44-Pin PLCC	U30
391638-01	IC, EPROM, Kickstart, CDGS, 512Kx16, 42-Pin DIP	U6; Programmed into 391639-01
391422-02	IC, Video DAC, BT101, 44-Pin PLCC	U30; Substitute for PN 391422-01 (Do not stuff D215 & R215)
391633-01	IC, DAC, Audio, LC78835M, SM	U31
391632-01	IC, SM, Dual Op Amp, TL082/LF353	U15A, U15B, U38B
391630-01	IC, Amp, Headphone, CXA1263AM, SM	U39
391631-01	IC, Linear, LM358, SM	U38A
391262-01	Voltage Regulator, 78L05, SM	U32
391635-03	IC, EEPROM, 24C08, SM	U9
391555-01	IC, SM, 74LS74A, EIAJ	U33; Substitute for PN 391141-01
391644-01	IC, 74HC4066, SM, EIAJ	U22, U36; Substitute for PN 391311-01
391656-01	IC, SM, Dual Op Amp, TL082/LF353, EIAJ	U15A, U15B, U38B; Substitute for PN 391632-01
<b>CONNECTORS</b>		
390242-01	D-SUB, 9-Pin, Male, DB9P	CN1, CN2 {Mouse/Joystick}
252122-03	RCA Jack, Yellow	CN10 {Composite Video}
252122-01	RCA Jack, White	CN4 {Left Audio}
252122-02	RCA Jack, Red	CN3 {Right Audio}
390272-01	DIN, 4-Pin, Round, Shielded	CN8 {CPU Power}
391648-01	Connector, Header, 10-Pin, 2.0mm, R-ANG.	CN14
390543-03	Connector, FPC, Vertical, 26-Pin	CN17 (CD ROM)
390851-02	Mini-DIN, 4-Pin, Round	CN9 {S-Video}
390851-04	Mini-DIN, 6-Pin, Round	CN13 {Keyboard}
<b>TRANSISTORS</b>		
391705-01	Transistor, JFET, MMBF5484L, SOT23	Q321, Q331
391121-01	Transistor, NPN, 2N3904, SOT23	Q201, Q281, Q282, Q346, (Q461), Q751, Q752, Q855, Q856, Q766, Q395, Q396
391122-01	Transistor, PNP, 2N3906, SOT23	Q341, Q342, Q632, Q633
391393-01	Transistor, SM, MOSFET, MMBF170, SOT23	Q355, Q356, Q365, Q366
391701-01	Transistor, SM, MOSFET, P-Channel, S1940ODY	Q765
391702-01	Transistor, MOSFET, P-Channel, 1RFD9020	Q765A (Substitute for PN 371701-01)
<b>DIODES</b>		
391561-02	Diode, ZENER. 6.3V, SOT23	D891
391129-01	Diode, 1N4148, SOT23	D281, D355, D356, D366, D365, D629
391128-01	Diode, 1N914, SOT23	Substitute for PN 391129-01
391327-01	Diode, SM, 1N4001, MELF PKG	D32, D641-D644

## PCB Assembly, CD Game System (365101 Rev D)

(cont'd)

391421-01	Voltage Reference, LM385, SO-8	D215 (Do not stull when using 391422-02)
391531-01	LM4041, Voltage Reference, 1.2V, SOT-23	D215A Substitute for 391421-01 (Do not stuff when using 391422-02)
	<b>FILTERS</b>	
391092-03	Filter, Ferrite, SM, (1206)	E321R, E331R, E351R, E361R, E353R, E358R, E363R, E368R, E325R
391092-01	Filter, Ferrite, SM, Large, (1812)	FB301A, FB401A, FB401B, FB402A, FB402B, FB641, FB750
391092-02	Filter, Ferrite, SM, Medium, (1206)	E231R, E281R, E282R, E622R, E623R, E626R, E627R, FB131, FB133, FB621-FB623, FB751, FB992
391138-02	Inductor, SM, 2.7uH, (1206)	L751
391138-01	Inductor, SM, 1.2uH, (1206)	(L241)
391146-02	Bandpass Filter, F-K5-MS	[Z221]
391147-02	Delay Line, F-K5-MD	(Z222)
391146-01	Bandpass Filter, BPF-K5-MS	(Z221)
391147-01	Delay Line, F-KS-MT	(Z222)
390253-04	Ferrite Bead, 2.5 Turn	LF1A-C
	<b>CAPACITORS</b>	
390818-03	Cap, SM, NPO, 15PF, (1206)	(C242)
390818-01	Cap, SM, NPO, 22PF, (1206)	E112C, E120C-E122C, (E124C), E127C, E129C, E375C-E377C, E643, E644, E762C
390818-07	Cap, SM, NPO, 33PF, (1206)	C751
390818-05	Cap, SM, NPO, 56PF, (1206)	(C241), C245
390818-06	Cap, SM, NPO, 100PF, (1206)	E231C, E281C, E282C, E621C-E627C, E641C, E642C
390818-08	Cap, SM, NPO, 120PF, (1206)	C772, C782
390853-06	Cap, SM, X7R, 470PF, (1206)	E351C, E353C, E354C, E361C, E363C, E364C, E374C
390853-07	Cap, SM, X7R, 1000PF, (1206)	(C243), C282, C460, C771, C781
390853-08	Cap, SM, X7R, 3900PF, (1206)	C323, C333
390853-09	Cap, SM, X7R, 6800PF, (1206)	C321, C322, C331, C332, E321C, E331C, E355C-E358C, E365C-E368C
390853-01	Cap, SM, X7R, .01UF, (1206)	C216, (C244), C246, C349, C800-C802
390853-04	Cap, SM, X7R, .047UF (1206)	C1B, C1D, C5B, C5D, C9, C12B, C25, C30A, C30B, (C33), C34, C37, C311-C314, C806
310027-02	Cap, SM, Z5U, .1UF, (1206)	C221, C222, C355, C365, E232C
390797-02	Cap, SM, CERM, SL/B/V, .22UF	C1A, C1C, C2A, C2B, C3, C4A, C4B, C5A, C5C, C6A, C6B, C12A, C15A, C15B, C16A, C16B, C17A, C17B, C18A, C18B, C19A, C19B, C22, C32, C35, C36, C38A, C38B, C39, C199, C211A-C211C, C217, C305, C352, C362, C641, C750, C761, C762, C804, C805, C881, C893
391637-02	Cap, SM, Elect. 4.7uF, Audio	C777, C787, C855, C865
390797-01	Cap, SM, CERM, SL/B/V, .33UF	C2X
310027-06	Cap, SM, Z5U, .47UF, (1206)	C31, C30C, C30D, C629

PCB Assembly, CD Game System (365101 Rev D)		(cont'd)
391231-13	Cap, SM, Tantalum, 10UF 16V, (C)	C407
391097-07	Cap, SM, Elect Alum, 10UF 25V, (C)	C214, C341, C791, C792
391097-08	Cap, SM, Elect Alum, 22UF 25V, (C)	C303, C459
391097-04	Cap, SM, Elect Alum, 47UF 16V, (D)	C235, C236, C885, C891, C892
391097-01	Cap, SM, Elect Alum, 100UF 6.3V, (D)	C237, C239, C409, C890, C281, C307, C790, C854, C864
390101-12	Cap, Elect Alum, 470UF, 10V	C821
390101-10	Cap, Elect Alum, 1000UF, 10V	C408, C811
<b>RESISTORS 1/8W 5%</b>		
310026-01	Resistor, SM, 47 Ohm (1206)	R155, R156, R371
310026-26	Resistor, SM, 0 Ohm (1206)	[R203], [R225], R801, R802
310026-24	Resistor, SM, 120 Ohm (1206)	R236
310026-42	Resistor, SM, 180 Ohm (1206)	(R236) R639
310026-10	Resistor, SM, 27 Ohm (1206)	E120R-E122R, E127R, E129R, E376R, E377R, E641R, E642R, R113-R115, R597, R598, E112R, E123R, E125R, R264
310026-12	Resistor, SM, 68 Ohm (1206)	(E124R), E131R-E134R, E374R, E375R, E751R, E752R, R151A-J, R152B-G, R239A-F, R261A-H, R262A-H, R263A-H, R265, R285, E621R, E624R, E643, E644, E761R, E762R, E753R
310026-05	Resistor, SM, 100 Ohm (1206)	R237, R282, R284
310026-14	Resistor, SM, 360 Ohm (1206)	R235
310026-56	Resistor, SM, 680 Ohm (1206)	R892
310026-25	Resistor, SM, 1.5K Ohm (1206)	R768
310026-21	Resistor, SM, 470 Ohm (1206)	R109, R324, R334, R341, R379, R593, R952A, R952B, R953A-F, R217, R751, R750
310026-11	Resistor, SM, 820 Ohm (1206)	R224, (R221)
310026-07	Resistor, SM, 1K Ohm (1206)	R101, R102, R104, R141, R142, R215, R222, [R221], (R244), R319, R511A, R511B, R633, R635, R643, R644, R881, R951A, R951B, R954A-E, R766, R853, R863 (Do not stuff when using 391422- 02)
310026-29	Resistor, SM, 75 Ohm (1206)	R232E, R234, R283
310026-16	Resistor, SM, 2.7K Ohm (1206)	(R245), [R246]
310026-08	Resistor, SM, 4.7K Ohm (1206)	R105, R153, R154, R202, R204, R219, (R241), R250-R253, R340, R342, R347, R348, R370A-R370H, R391, R392, R397, R398, R634, R636, R752, R754, R756, R763A-R763H, R771, R772, R775, R781, R782, R855, R865, R951C-G, R954F, R954G, R397, R398
310026-35	Resistor, SM, 6.8K Ohm (1206)	(R242), R767, R779, R789
310026-64	Resistor, SM, 8.2K Ohm (1206)	R851, R861
310026-50	Resistor, SM, 18K Ohm (1206)	R773, R776, R779, R789
310026-17	Resistor, SM, 10K Ohm (1206)	R209, (R243), R322, R323, R332, R333, R628, R629, R760, R761, R762, R770
310026-42	Resistor, SM, 180 Ohm, (1206)	R639

## PCB Assembly, CD Game System (365101 Rev D)

(cont'd)

310026-38	Resistor, SM, 2.2K Ohm (1206)	R281
310026-22	Resistor, SM, 330 Ohm (1206)	R320, R321, R330, R331
310026-23	Resistor, SM, 22K Ohm (1206)	R778, R788
310026-18	Resistor, SM, 33K Ohm (1206)	R349, R774, R784
310026-03	Resistor, SM, 47K Ohm (1206)	R344, R753, R755, R395, R396
310026-31	Resistor, SM, 100K Ohm (1206)	R345, R777, R787, R856, R866
310026-19	Resistor, SM, 470K Ohm (1206)	R326, R336
310026-53	Resistor, SM, 10M Ohm (1206)	R355, R365
310026-62	Resistor, SM, 82K Ohm (1206)	R327, R337
<b>RESISTORS 1/8W,1%</b>		
391154-13	Resistor, SM, 1/8W, 1%, 15 Ohm (1206)	R216
391154-14	Resistor, SM, 1/8W, 1%, 24.9 Ohm (1206)	R232A-R232C
391154-12	Resistor, SM, 1/8W, 1%, 49.9 Ohm (1206)	R231A-R231C
391154-42	Resistor, SM, 1/8W, 1%, 866 Ohm (1206)	[R223]
391154-03	Resistor, SM, 1/8W, 1%, 1K Ohm (1206)	R303, R304, R892
391154-39	Resistor, SM, 1/8W, 1%, 27 hm (1206)	R459
391154-43	Resistor, SM, 1/8W, 1%, 698 Ohm (1206)	(R223)
<b>RESISTORS 1/8W,5%</b>		
391093-01	Resistor, SM, 1W, 5%, 1 Ohm (2512)	R309
391093-02	Resistor, SM, 1W, 5%, 4.7 Ohm (2512)	E232R, R352, R362
391154-39	Resistor, SM, 1/8W, 1%, 27K Ohm (1206)	R459
310026-50	Resistor, SM, 1/8W, 5%, 18K Ohm (1206)	R773, R776, R783, R786
<b>MISCELLANEOUS</b>		
252182-01	Switch, Rocker, DPDT, R-Angle, PC-MT	SW1
252182-02	Switch, Rocker, DPDT, R-Angle, PC-MT	Substitute for PN 252182-01
252345-01	Crystal, 4.433619 MHz	(Y451)
325566-14	Oscillator, 28.63636 MHz	[X1]
252344-01	Oscillator, 28.37516 MHz	(X1)
391693-01	Oscillator, 16.9344 MHz	X3
313371-01	Modulator, MDG-VA3424	[X2]
313371-05	Modulator, MDG-UD3626	(X2)
904500-02	Switch, Rocker, DPDT, R-Ang, PC-MT	SW1; Substitute for PN 252182-01

## Main Assembly/CDGS Player (365158 Rev C)

365158-01	Main Assembly: PAL/CDGS Player	
365158-02	Main Assembly: NTSC/CDGS Player	
365160-01	Top Assembly/CDGS Player	
365159-01	Bottom Assembly: PAL/CDGS Player	
365159-02	Bottom Assembly: NTSC/CDGS Player	
390146-01	Screw, Torx Drive, Hi-Lo Flute, M3 x 8.0 LG	
390177-02	Screw, Torx Drive, Tri-Lobe	Substitute for PN 390146-01
369651-01	Label, Laser Caution	
906810-19	Screw, Machine, M4 x 0.7 x 12.0 LG	
365306-01	Nut, Speed, 'U' Type, M4 x 0.7	

**Bottom Assembly: CDGS Player (365159 Rev B)**

365159-01	Bottom Assembly: PAL/CDGS Player
365159-02	Bottom Assembly: NTSC/CDGS Player
365101-02	PCB Assembly: PAL/CDGS Player
365101-01	PCB Assembly: NTSC/CDGS Player
365167-01	Shield, Top
365166-01	Shield, Bottom
365216-01	Insulation Sheet
313376-03	Cable, Flexible Flat
365195-01	Bottom Case
310080-02	Foot, Rubber, Black

**Bottom Assembly: CDGS Player (365159 Rev B)****(cont'd)**

369652-01	Label, Laser Date	
369630-02	Rating Label/VDE	Made in Phillipines
369630-01	Rating Label/FCC	Made in Phillipines
369630-01	Rating Label/Brazil	Used for Brazil only
390146-01	Screw, Torx Drive, Blunt Pnt, ST, Hi-Lo Flute	
390177-01	Screw, Torx Drive, Tri-Lobe	Substitute for PN 390146-01
365367-01	Cable, LED	
365367-02	Cable, LED with Torroid (1 turn)	
365193-01	Cover, Expansion	

**Top Assembly/CDGS Player (365160 Rev A)**

365160-01	Top Assembly/CDGS Player	
365161-01	CD ROM Drive Assembly	
365169-01	Lid Assembly	
365172-01	Hinge Mechanism Assembly	
365171-01	Hinge Pin	
365196-01	Top Case	
365168-01	LED PCB Assembly CDGS/P	
365219-01	Button, Reset	
365218-01	Button, Volume	
365282-01	Spring	Use with PN 365219-01
365301-01	Nameplate, CDGS (Amiga CD32)	
365012-03	Screw, Flat Head, Mach., M2 x 6.0 LG	Hinge Mechanism (Black)
390146-01	Screw, Torx T-10 Drive, M3 x 8.0mm, PH	LED PCB Assy/Drive Mech.
906921-03	Screw, Flat Head, Self Tap., M2.5 x 4.0 LG	(Black) for PN 365171-01
906803-07	Screw, Flat Head, Mach., M3 x 5 LG	(Black)
390177-02	Screw, Torx Drive, Tri-Lobe	Substitute for PN 390146-01
390177-01	Screw, Torx Drive, Tri-Lobe	Substitute for PN 390146-01
365366-01	Lubricant, Lithium	For PN 365172-01, Hinge Mechanism

**CD ROM Drive Assembly/CDGS Player (365161 Rev A)**

365161-01	CD ROM Drive Assembly
365181-01	CD ROM Mechanism
365194-01	Mounting Plate
365180-01	Insulator- "K" Type

**CD ROM Drive Assembly/CDGS Player (365161 Rev A) (cont'd)**

365179-01	U-Spring, Front, (Silver, Light)	Spring 'B'
365178-01	U-Spring, Rear, (Gold, Heavy)	Spring 'A,' Motor Side
365177-01	Controller PCB Assembly	
365176-01	Cable, Head Mechanism	
365176-02	Cable, Head Mechanism	
365175-01	Cable, Drive	
365174-01	Spindle/Lens Cover	
365173-01	Shield, Controller PCB	
365197-01	Screw, Shoulder	Used with PN 365180-01, 365179-01, 365178-01
365224-01	Standoff, Hex, Female/Male, M3 x 11	
365236-01	Screw, Pan HD, Self Tap, M2 x 5 LG AB	For mounting PN 365174-01
390146-04	Torx T-10 Drive M3 x 5mm, PH	For mounting PN 365177-01, 365173-01, 905655-03 and 365223-01
905655-03	Washer, External Tooth Lock, M3	
365223-01	Insulation Sheet	
390177-04	Screw, Torx Drive, Tri-Lobe	Substitute for PN 390146-04

**Disk Chucking Assembly/CDGS Player (365163 Rev A)**

365163-01	Disk Chucking Assembly
365191-01	Magnet
365190-01	Chucking Plate "A"
365189-01	Washer 80 x 45 x .5
365188-01	Chucking Plate "B"
365230-01	Screw, M2 x 3.0, Mach.

**PCBA, CDGS, LED/Audio (365168 Rev B)**

365168-01	PCB Assembly, CDGS, LED/Audio	
365229-01	Schematic, CDGS, LED/Audio PCB	
365228-01	PCB Fab, CDGS, LED/Audio PCB	
365227-01	Artwork, CDGS, LED/Audio PCB	
391636-01	Switch, DPDT, Pushbutton, Vert	SW1
391634-01	POT, 50K, Single, Slide, Audio	VR1
391649-01	Headphone Jack, Stereo, 3.5mm, Vert	J1
252018-02	LED, 2 x 15mm, Green	D2
252018-05	LED, 2 x 15mm, Yellow	D1
365373-01	Spacer, LED	
390904-03	Resistor, 1/4W, 5%, 22 Ohm, 5mm	R1, R2
391648-01	Header Assy, R-Ang, 2.0mm, 10 Pos	P1
390904-26	Resistor, Carbon Film, 1/4W, 5%, 33K Ohm	R5
390904-18	Resistor, Carbon Film, 1/4W, 5%, 10K Ohm	R4
390904-32	Resistor, Carbon Film, 1/4W, 5%, 180 Ohm	R3
901550-63	Resistor, Carbon Film, 1/4W, 5%, 22 Ohm	Substitute for PN 390904-03
901550-06	Resistor, Carbon Film, 1/4W, 5%, 33K Ohm	Substitute for PN 390904-26
901550-20	Resistor, Carbon Film, 1/4W, 5%, 10K Ohm	Substitute for PN 390904-18



---

**PCBA, CDGS, LED/Audio (365168 Rev B)** (cont'd)


---

901550-100	Resistor, Carbon Film, 1/4W, 5%, 180 Ohm	Substitute for PN 390904-32
390082-05	Capacitor, Ceramic, Axial, .22uF, 50V	C1
391670-01	Phototransistor, IR, Side Looking	Q1
391672-01	LED, IR, Side Emitting	D3

---

**Cable, LED (365367 Rev B)**


---

365367-01	Cable Assembly, CDGS, LED	
365367-02	Cable Assembly, CDGS, LED, with Ferrite Torroid, 1 Turn	
365367-03	Cable Assembly, CDGS, LED, with Ferrite Torroid, 2 Turns	
200016-113	Wire, Lead, 26 AWG, Black, Standard, 350mm	1.6mm-2.1mm Strip Length
200016-114	Wire, Lead, 26 AWG, Black, Standard, 400mm	1.6mm-2.1mm Strip Length
200016-115	Wire, Lead, 26 AWG, Black, Standard, 450mm	1.6mm-2.1mm Strip Length
391710-01	Crimp Terminal, 2mm Wire to Board	
391709-01	Housing, 10 Position, 2mm Wire to Board	
391708-01	Connector, 10-pin IDT, 2mm Wire to Board	Substitute for 391710-01 and 391709-01
906115-02	Torroid, Ferrite Ring	

---

**Lid Assembly/CDGS Player (365169 Rev A)**


---

365169-01	Lid Assembly
365170-01	Lid
365163-01	Disk Chucking Assembly
365234-02	Retaining Ring
365215-01	Viewing Window
365236-01	Screw, M2 x 5, Pan Head, Self Tapping
365235-01	Stop, Rubber

---

**Hinge Mechanism Assembly (365172 Rev A)**


---

365172-01	Hinge Mechanism Assembly
365200-01	Spring, Lid
365201-01	Pivot Arm
365203-01	Base Pivot

---

**Shipping Assembly CDGS Player (513515 Rev C)**


---

513515-01	Shipping Assembly CDGS Player, US
513515-02	Shipping Assembly CDGS Player, CN
513515-03	Shipping Assembly CDGS Player, UK
513515-04	Shipping Assembly CDGS Player, GR
513515-05	Shipping Assembly CDGS Player, FR
513515-06	Shipping Assembly CDGS Player, IT
513515-07	Shipping Assembly CDGS Player, SP
513515-08	Shipping Assembly CDGS Player, SG
513515-09	Shipping Assembly CDGS Player, SF

## Shipping Assembly CDGS Player (513515 Rev C)

(cont'd)

513515-10	Shipping Assembly CDGS Player, AU	
513515-11	Shipping Assembly CDGS Player, NR	
513515-12	Shipping Assembly CDGS Player, SD	
513515-13	Shipping Assembly CDGS Player, FN	
513515-14	Shipping Assembly CDGS Player, NE	
513515-15	Shipping Assembly CDGS Player, DN	
513515-16	Shipping Assembly CDGS Player, BF	
513515-17	Shipping Assembly CDGS Player, BD	
513515-18	Shipping Assembly CDGS Player, AL	
513515-19	Shipping Assembly CDGS Player, CEL	
513515-20	Shipping Assembly CDGS Player, PG	
513515-21	Shipping Assembly CDGS Player, JP, Not Used	
513515-22	Shipping Assembly CDGS Player, INT, Not Used	
513515-23	Shipping Assembly CDGS Player, LA, NTSC	
513515-24	Shipping Assembly CDGS Player, PD, Not Used	
513515-25	Shipping Assembly CDGS Player, LA, PAL	
513515-26	Shipping Assembly CDGS Player, LA, Brazil	
513515-27	Shipping Assembly CDGS Player, SI	
364346-02	Box, Accessory	
364055-03	Master Shipping Box	4 Up
364056-03	Packing Box	1 Up
365302-01	Tray, Packing	
365158-01	Main Assembly (PAL)	
365158-02	Main Assembly (NTSC)	
365299-01	Endcap	
1540025-01	Poly Bag	
324257-02	Bag, Drying Agent	
904778-01	RF Switch Box	
326189-01	Cable, RF (NTSC)	
251846-04	Cable, RF (PAL)	
311945-01	Cable Assembly, Audio	
365183-01	Game Controller	
313375-01	Power Supply, UL/CSA	110V
313375-02	Power Supply, BSI	240V
313375-03	Power Supply, VDE	220V
313375-04	Power Supply, SEV	220V
313375-05	Power Supply, SAA	220V
313375-06	Power Supply, Brazil	220V
371189-01	Consumer Information Sheet	Multilingual
318896-05	Software License Agreement	English
318708-02	Software License Agreement	German
318365-04	Warranty Card	US
318882-02	Warranty Card	CN
320046-06	Warranty Card	GR
325254-01	Warranty Card	FR

## Shipping Assembly CDGS Player (513515 Rev C)

(cont'd)

369270-01	Warranty Card	UK
318876-03	Service Center List	AL
368084-01	Seal, Tamper Evident	
318143-02	Glue, White	
999104-01	Adhesive Tape, Transparent, 50mm	
369632-01	Label, UPC	
366648-01	Label, Bar Code, 0.5" X 1.75"	
371133-01	User's Guide, CDGS Player	UK Eng
371208-01	User's Guide, CDGS Player	US Eng
371212-01	User's Guide, CDGS Player	FR
371214-01	User's Guide, CDGS Player	GR
371213-01	User's Guide, CDGS Player	IT
371219-01	User's Guide, CDGS Player	NE
371220-01	User's Guide, CDGS Player	DN/NR
371216-01	User's Guide, CDGS Player	SD/FN
371215-01	User's Guide, CDGS Player	SP/PG
365300-01	Sleeve, Color	US
365300-02	Sleeve, Color	CN
365300-03	Sleeve, Color	UK
365300-04	Sleeve, Color	GR
365300-05	Sleeve, Color	FR
365300-06	Sleeve, Color	IT
365300-07	Sleeve, Color	SP
365300-08	Sleeve, Color	SG
365300-09	Sleeve, Color	SF
365300-10	Sleeve, Color	AU
365300-11	Sleeve, Color	NR
365300-12	Sleeve, Color	SD
365300-13	Sleeve, Color	FN
365300-14	Sleeve, Color	NE
365300-15	Sleeve, Color	DN
365300-16	Sleeve, Color	BF
365300-17	Sleeve, Color	BD
365300-18	Sleeve, Color	AL
365300-19	Sleeve, Color	CEL
365300-20	Sleeve, Color	PG
365300-23	Sleeve, Color	LA, NTSC
365300-25	Sleeve, Color	LA, PAL
365300-26	Sleeve, Color	Brazil
365300-27	Sleeve, Color	SI